

General Wood Instructions

Sanding

The rule of sanding is "Never across the grain".

1. Do not tear sandpaper. If you do, the ragged edges will often scratch the wood surface.
2. For flat surfaces, wrap a piece of sandpaper around a block of wood or use a store bought holder. Start with a coarse grade of paper and finish with a fine grade of paper(not included).
3. Be consistent. Do not sand one area with fine and another with coarse grade.

Staining

1. Be sure the wood surface is smooth and clean. Stains can accentuate any roughness or scratches of cross grain sanding. Wipe off any dirt or dust with a soft cloth.
2. A base coat of sealer/primer and a light sanding before applying stain will insure a uniform stain.
3. Apply stains in one direction following the wood grain. Use a soft brush or foam brush. Let the stain penetrate the wood, then wipe off excess stain with a soft cloth.
4. If stain looks too dark, dampen the cloth with water/thinner and wipe until you achieve the desired color. If stain is too light, let dry, then apply another coat of stain and wipe off.

Finishes

1. Outdoor projects may be finished with polyurethane or varnish.

These are toxic and must be used in a well ventilated area. Indoor projects may be finished with decoupage or left unfinished.

Safety First!

This Product May Contain Silicon Gel Packets.
REMOVE PRIOR TO USE!

Butterfly House Item# WD3344

S&SWorldwide

CALL TOLL-FREE 1-800-243-9232

or **Mail Your Order** to: S&S Worldwide
PO Box 513

Colchester, CT 06415-0513

FAX #: 1-800-566-6678

Customer Service: 1-800-937-3482

Internet home page address: <http://www.ssworld.com>

Email address: service@ssworld.com

Item No. WD3344

Made in China

Butterfly House

PLEASE READ ALL INSTRUCTIONS BEFORE STARTING



- ☒ Precut Wooden Pieces
- ☒ Sandpaper
- ☒ Instructions

YOU WILL NEED...



Protected Work Surface
Soft Cloth
Paint or Stain
Brushes
Glue

PREP TIME: 10-15 MIN

PROJECT TIME: 45 MIN



WARNING:

CHOKING HAZARD - Small parts. Not intended for children under 3 years.

SUFFOCATION HAZARD - To avoid danger of suffocation, keep plastic bags away from babies and children. Do not use bags in cribs, carriages, or playpens.

S&SWorldwide



Product Instructions:

- 1 Sand all wooden parts until smooth. Wipe off excess dust with a soft cloth.
- 2 Paint or stain pieces as desired. Let dry.
- 3 Apply glue to one edge of each side piece and hold firmly to the back piece, making sure edges are flush.
- 4 Apply glue to front edge of side pieces and hold the front piece firmly in place, making sure edges are flush.
- 5 Apply glue to the bottom edges of the side, front and back pieces. Center on the bottom piece and hold firmly in place.
- 6 Apply glue to the top edges of the front and back, as well as the top edge of the top right roof piece. Overlap the top right piece with the top left piece as shown in Figure A. Hold firmly in place until bond forms.

FIGURE A

