WD7341

Wooden Pine Tree (Pk/6)

GENERAL WOOD INSTRUCTIONS

Sanding

The rule of sanding is "Never across the grain".

- 1. Do not tear sandpaper. If you do, the ragged edges will often scratch the wood surface.
- 2. For flat surfaces, wrap a piece of sandpaper around a block of wood or use a store bought holder. Start with a coarse grade of paper and finish with a fine grade of paper(not included).
- 3. Be consistent. Do not sand one area with fine and another with coarse grade.

Staining

- 1. Be sure the wood surface is smooth and clean. Stains can accentuate any roughness or scratches of cross grain sanding. Wipe off any dirt or dust with a soft cloth.
- 2. A base coat of sealer/primer and a light sanding before applying stain will insure a uniform stain.
- 3. Apply stains in one direction following the wood grain. Use a soft brush or foam brush. Let the stain penetrate the wood, then wipe off excess stain with a soft cloth.
- 4. If stain looks too dark, dampen the cloth with water/thinner and wipe until you achieve the desired color. If stain is too light, let dry, then apply another coat of stain and wipe off.

Finishes

1. Outdoor projects may be finished with polyurethane or varnish.

These are toxic and must be used in a well ventilated area. Indoor projects may be finished with decoupage or left unfinished.

MAKING IT EASY to SAVE MORE on your next order!

\$100FF
Your Next Order of only \$3900 or more.

Please mention Offer Code: M2467

Minimum order \$39 excludes shipping and taxes.
Limit one per order.
May not be combined with other offers
or bid or contract pricing.

See current S&S® catalog or Help at ssww.com for Offer Terms and Conditions. We reserve the right to terminate this offer at any time without notice.

Call Toll-Free **1-800-243-9232**

Online: SSWW.COM



Customer Service: 1-800-937-3482

Email: cservice@ssww.com

FAX: 1-800-566-6678 Reorder Number

WD7341

1.0



Wooden Pine Tree (Pk/6)

PLEASE READ ALL INSTRUCTIONS BEFORE STARTING



YOUR KIT CONTAINS:

- Wood Pieces
- Sandpaper
- Screw
- Instructions

PREP TIME: 5 minutes
PROJECT TIME: 30 minutes
(plus drying time)

YOU WILL NEED:

- Soft Cloth
- Paint or Stain
- Phillips Screwdriver
- Brushes
- Protected Work Surface



© Copyright 2012 S&S® Worldwide Inc. All rights reserved. No part of this project may be copied or duplicated without the express written permission of S&S Worldwide.

INSTRUCTIONS:

- 1. Sand wood pieces until smooth. Remove dust with a soft cloth.
- 2. It is easier to stain or paint the pieces before assembly. A combination of paint and stain looks great. Let dry 30 minutes or until thoroughly dry.
- 3. Assemble by attaching the base to the bottom of the tree using screw provided. Be sure to screw all the way into the hole so that none of the screw remains extending out of the hole. This will ensure that the tree sits level.



Log onto **ssww.com** for paint, stain, decoupage, brushes and other decorating supplies!