

General Wood Instructions

Sanding

The rule of sanding is "Never across the grain".

1. Do not tear sandpaper. If you do, the ragged edges will often scratch the wood surface.
2. For flat surfaces, wrap a piece of sandpaper around a block of wood or use a store bought holder. Start with a coarse grade of paper and finish with a fine grade of paper(not included).
3. Be consistent. Do not sand one area with fine and another with coarse grade.

Staining

1. Be sure the wood surface is smooth and clean. Stains can accentuate any roughness or scratches of cross grain sanding. Wipe off any dirt or dust with a soft cloth.
2. A base coat of sealer/primer and a light sanding before applying stain will insure a uniform stain.
3. Apply stains in one direction following the wood grain. Use a soft brush or foam brush. Let the stain penetrate the wood, then wipe off excess stain with a soft cloth.
4. If stain looks too dark, dampen the cloth with water/thinner and wipe until you achieve the desired color. If stain is too light, let dry, then apply another coat of stain and wipe off.

Finishes

1. Outdoor projects may be finished with polyurethane or varnish.

These are toxic and must be used in a well ventilated area. Indoor projects may be finished with decoupage or left unfinished.

Safety First!

This Product May Contain Silicon Gel Packets.
REMOVE PRIOR TO USE!

Door Knob Hangers Item# WD3170

S&SWorldwide

CALL TOLL-FREE 1-800-243-9232

or **Mail Your Order** to: S&S Worldwide
PO Box 513

Colchester, CT 06415-0513

FAX #: 1-800-566-6678

Customer Service: 1-800-937-3482

Internet home page address: <http://www.ssworld.com>

Email address: service@ssww.com

Item No. WD3170

Made in China

Door Knob Hangers

PLEASE READ ALL INSTRUCTIONS BEFORE STARTING



- ☒ Wood Figures
- ☒ Sandpaper
- ☒ Instructions

YOU WILL NEED...



Soft Cloth
Paint or Stain
Protected Work Surface
Wood Finish (optional)

PREP TIME: 5 MIN

PROJECT TIME: 30 MIN



WARNING:

CHOKING HAZARD - Small parts. Not intended for children under 3 years.

SUFFOCATION HAZARD - To avoid danger of suffocation, keep plastic bags away from babies and children. Do not use bags in cribs, carriages, or playpens.

S&SWorldwide



Product Instructions:

- Remove the desired figure from the board.
- Sand any rough edges. If you sand the face, do so lightly, taking care not to remove any of the printed lines.
- Paint the figure. when dry, you may apply a coat of clear finish (decoupage or polyurethane) if desired. Let dry completely.

More Ideas!

Make your figure more decorative by adding trims and ribbons.



Log on to **www.ssw.com** for paint, stain, decoupage, brushes and other decorating supplies!

