



W10746 Team Scooter Ball Launcher Instructions

Contents: Two sling shot style, Y shaped, ball launchers.

Required Materials: 2-Person Scooters (W9513 Set of 2 or W9450 Set of 6), 1 for each ball launcher. Foam Balls like GatorSkin Super- 70 (W6148, W9150) or GatorSkin Super-90 (W6149, W9476), W4805 Super Bounce Balls, W4902 Marshmallow Balls, SL9993 Smile Face Balls, or other soft balls with a diameter of 3" or less.

Installing the Ball Launcher: Align the bottom of the launcher with one of the holes in either end of the scooter (not the center hole). Push down on the elbow of the launcher until it bottoms out as shown in the images below. Note that the elbow will face away from the user and the elastic will attach to the tubing on the side that is furthest away from the user.



Using the Launcher: Place a ball on the elastic band on the opposite side the user. Using one or two hands to secure the ball, pull back on the elastic and the release the ball and the elastic simultaneously.

