

W8453 Bowling Buddy Instructions

Uses:

Your Bowling Buddy can be used for a variety of activities.

- **Bowling** – it makes a great background, making it easier for players to focus on the pins and keeps all the pins nearby.
- **Beanbag Toss** – grab your favorite set of beanbags and use the numbers printed on your Bowling Buddy for a fun game of beanbag toss.
- **Horseshoes** – Order a set of our W2334 or W3400 indoor horseshoes and use your Bowling Buddy as the perfect horseshoe pit.

Inflation:



Your Bowling Buddy includes two inflation valves. Use any air pump designed for inflating larger inflatables, like cage balls. Our W5970, W2407 and W10085 pumps will inflate the Bowling Buddy within a few minutes. Care should be taken if attempting to use a high pressure ball or tire pump to inflate the Bowling Buddy – Do not over inflate the Bowling Buddy and be careful the pump does not overheat. When using the Bowling Buddy as a bowling background, it is recommended that the lower chamber not be fully inflated. This will help the background absorb some of the energy of the balls and pins that hit it and prevent them from rebounding back into the pins that are still standing.

For Bowling:

Your Bowling Buddy can be used as a background for bowling with or without a bowling carpet (like our W7029 Bowling Carpet and W8454 Multi-Purpose Carpet). It is recommended that the leading edge of the Bowling Buddy be taped to the floor using floor tape. When using it with a carpet, we recommend the carpet be positioned as shown below. The edge of the carpet should butt up against the line just behind the pin set-up area. The back end of the carpet may optionally be taped down to the Bowling Buddy.

