

Jenga® QUAKE


THE FIRST TIME YOU PLAY

Insert the batteries (see Battery Information, below).

PREPARE FOR THE JENGA® QUAKE!



1. BUILD THE TOWER.

Place three blocks per layer, alternating direction by layer. Decide who goes first.



2. PRESS THE POWER BUTTON.

The LED will begin to pulsate slowly.




3. GO! THE TOWER CAN START TO QUAKE AT ANY TIME.

Play quickly, before the blocks crash!

ON YOUR TURN

1. WITH ONLY ONE HAND, remove a block from anywhere below the highest completed layer.




2. PLACE THE BLOCK ON TOP OF THE TOWER.

Wait 5 seconds.



- If the tower falls before 5 seconds pass, you lose and you must rebuild the tower to start a new game.
- If the tower remains standing for 5 seconds, the next player is up.



HOW TO WIN

Be the last player to stack a block without causing the tower to crash!

If you are playing solo, try to beat your own highest tower.

MORE TO KNOW

- When the base is ON, the LED is lit.
- After 10 minutes, the LED will blink rapidly and then the base will go to sleep. To keep the base on or to wake it up, press the power button and the cycle of random vibrations will resume.
- Turn the base OFF when you are finished playing by pressing

and holding the power button for more than two seconds.

- If the base does not function properly after batteries are replaced, push in the reset button, located in the battery compartment (use a paperclip if necessary).
- If the tower falls in the brief time between two players' turns, the first player rebuilds the tower and the game continues with no penalty to either player.
- Block colors are decorative only and do not affect gameplay.

JENGA® is a registered trademark of Pokonobe Associates. © 2013 Pokonobe Associates. Used under license from Pokonobe Associates. All Rights Reserved. TM & ® denote U.S. Trademarks.

Duracell and its logo are trademarks of Procter & Gamble and are used with permission. © 2013 Procter & Gamble. All rights reserved.

HASBRO GAMING and its logo are trademarks of Hasbro. © 2013 Hasbro, Pawtucket, RI 02861-1059 USA. All Rights Reserved. TM & ® denote U.S. Trademarks.

Consumer contact: USA and Canada: Hasbro Games, Consumer Affairs Dept., P.O. Box 200, Pawtucket, RI 02861-1059 USA. ☎ 888-836-7025.

Hasbro Australia Ltd., Level 2, 37-41 Oxford Street, Epping, NSW 2121, Australia. ☎ 1300 138 697.

Hasbro NZ (a branch of Hasbro Australia Ltd.), 221 Albany Highway, Auckland, New Zealand. ☎ 0508 828 200.

FCC Statement This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.



Battery Information


To insert batteries: Phillips/cross head screwdriver (not included) needed to insert batteries.

POWER UP WITH
BATTERIES
NOT INCLUDED



x3 1.5VAA
ALKALINE BATTERIES
REQUIRED NOT INCLUDED

Reset Button



IMPORTANT: BATTERY INFORMATION



CAUTION: 1. TO AVOID BATTERY LEAKAGE:

a. Always follow the instructions carefully.

Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings. b. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries. c. Remove exhausted or dead batteries from the product. d. Remove batteries if product is not to be played with for a long time. e. Do not short-circuit the supply terminals.

f. **RECHARGEABLE BATTERIES:** Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. **DO NOT RECHARGE OTHER TYPES OF BATTERIES.** 2. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.