

**W12824 Sky High Stilts™**  
**Use Instructions and Warnings**



**WARNING!** Please read the information below carefully before using your stilts.



**WARNING!** Choking Hazard. Contains Small Parts. Keep small parts and plastic bags out of children's reach during and after assembly.

- Adult Assembly Required.
- To avoid serious injury adult supervision is required.
- Never use the stilts near motor vehicles, streets, swimming pools, on hills, steps, sloped driveways or any wet surface.
- Always wear shoes when using the stilts.
- Do not modify this product in any way.

**Recommendations:**

- This product is designed for users weighing up to 250 pounds.
- Users should always wear a properly fitted helmet that complies with US Consumer Product Safety Commission (CPSC) standard 16CFR1203.
- Users should always wear protective knee, elbow and wrist guards.
- Users should avoid wearing anything that obstructs their vision or hearing.
- Periodically check the rubber cap at the bottom of the stilts for wear. If there is excessive wear the rubber tip should be replaced.

**Height Adjustment Instructions:**

1. Remove key ring on the pin similar to the way you would remove a ring from a key or set of keys.
2. Adjust the location of the foot step to the desired height. Be sure that both stilts are set at the same height.
3. Replace pin. Be sure that the pin passes through both the foot step and main tube / pole of the stilt.
4. Replace the key ring in the end of the hole of the pin. Be sure the key ring is completely on the pin. This step is critical to assure the foot step is secure on the pole and will not fall off.
5. Do not exceed the 250 pound weight limit for the users of the stilts.

