

GA7519B

Classic Cars - Touring Car

**PLAY. LEARN. SHARE.**

[ssww.com/blog](http://ssww.com/blog)

**Find ideas on the S&S Blog:**

- Crafts & DIY
- Senior Activities
- Summer Camp
- Education & Classroom



@SSWorldwidecatalog



@ssworldwide



@ssworldwide



@SSWorldwide

**MAKING IT EASY to SAVE MORE on your next order!**

**15% OFF**  
No \$ Minimum

Please mention Offer Code: **M2467**

Limit one per order.

May not be combined with other offers  
or bid or contract pricing.

See [ssww.com](http://ssww.com) for Offer Terms and Conditions.

We reserve the right to terminate this  
offer at any time without notice.

Call Toll-Free  
**1-800-243-9232**

Online:  
**SSWW.COM**

Email:  
**cservice@ssww.com**

FAX:  
**1-800-566-6678**

**S&S**Worldwide

© Copyright 2018 S&S® Worldwide Inc. All rights reserved.  
No part of this project may be copied or duplicated without the express written permission of S&S Worldwide.

**Kit may contain silicone gel packets, which should be removed before use.**

Reorder Number


GA7519B

1.1

**S&S**® Worldwide  
**MAKING IT EASY**  
to Help People Play and Learn Since 1906

**Classic Cars - Touring Car**

PLEASE READ ALL INSTRUCTIONS BEFORE STARTING



**YOUR KIT CONTAINS:**

- Wood Pieces
- Wood Dowels
- 4 Metal Rivets

**YOU WILL NEED:**

- Wood Glue
- Ruler
- Sandpaper (Optional)
- Acrylic Craft Paint (Optional)
- Stain (Optional)
- Brushes (Optional)
- Flat Work Surface

**PREP TIME: 10 minutes**  
**PROJECT TIME: 30 minutes**

## INSTRUCTIONS:

1. Before starting, read through instructions, then lay out and identify each piece. All parts are pre-sanded, but finish sanding is suggested. Remove any excess dust with a soft cloth after sanding.
2. Stain or paint the wood parts if desired. A combination of stain and paint looks nice. Let dry 30 minutes (Make sure when gluing to allow pieces to dry between steps).
3. Glue axles (1-1/2" x 1/8") flush to front and rear of the chassis (3" x 1-3/16"). Attach wheels by pushing the metal rivets through wheels and into axle holes (See Figure A).
4. Glue steps (1-1/2" x 1/2") to the bottom of chassis, centered between wheels and flush with middle wheel (See Figure B).
5. Glue steamer trunk (1/2" x 3/8") centered on rear of chassis flush with top edge of chassis. Glue tool box (1/2" x 3/8") to front end of step (See Figure C).
6. Glue small seat centered left to right and flush to rear edge of the chassis (See Figure D).
7. Glue side panels (7/8" x 1/2") flush to sides of the back (small) seat and rear edge of chassis (See Figure E).
8. Glue large seat to chassis, flush to front of side panels. Glue convertible top behind the back seat flush with the top seat (See Figure F).
9. Glue two headlights (5/16" stubby dowels) on each side of the hood flush to top and extending about 1/8" beyond front of hood. Glue steering wheel to steering post (1/8" x 1/2" dowel). Glue steering post into hole in the firewall (See Figure G).
10. Glue firewall to back of hood (See Figure H).
11. Glue hood assembly (Step 10) flush to front of chassis (See Figure I).

## GENERAL WOOD INSTRUCTIONS:

### SANDING

The rule of sanding is "Never across the grain."

1. Do not tear sandpaper. If you do, the ragged edges will often scratch the wood surface.
2. For flat surfaces, wrap a piece of sandpaper around a block of wood or use a store bought holder. Start with a coarse grade of paper and finish with a fine grade paper (not included).
3. Be consistent. Do not sand one area with fine paper and another with coarse grade paper.

### STAINING

1. Be sure the wood surface is smooth and clean. Stains can accentuate any roughness or scratches of cross grain sanding. Wipe off any dirt or dust with a soft cloth.
2. A base coat of sealer/primer and a light sanding before applying stain will ensure a uniform stain.
3. Apply stains in one direction following the wood grain. Use a soft brush or foam brush. Let the stain penetrate the wood, then wipe off excess stain with a soft cloth.
4. If stain looks too dark, dampen the cloth with water/thinner and wipe until you achieve the desired color. If stain is too light, let dry, then apply another coat of stain and wipe off.

### FINISHES

1. Outdoor projects may be finished with polyurethane or varnish. **These are toxic and must be used in a well ventilated area.** Indoor projects may be finished with decoupage or left unfinished.

FIG. A




FIG. B




FIG. C




FIG. D




FIG. E




FIG. F




FIG. G




FIG. H




FIG. I

